

BLUEDEE

Manufacturer:

Shenzhen Hanke Technology Co., Ltd

Address:

Meipeng SKY311, No.3 Hebei Industrial Zone, Zhongxing Road, Ma'antang Community,
Bantian Street, Longgang District, Shenzhen, Guangdong, China, 518000

E-mail:

support@bluedee.com

IC: 29114-SK200



Made in China

BLUEDEE



Model:SK200

PC Gaming Soundbar / PCサウンドバー


User Guide / 取扱説明書

CONTENTS


English 1-14

日本語 15-28

PACKAGE CONTENTS



①



②



③



④



⑤


- ① 1 x Power Adapter
- ② 1 x 3.5mm Audio Cable
- ③ 1 x User Guide
- ④ 1 x Sound Bar (Model: BD-SK200)
- ⑤ 1 x Wall mounting guide card

PRODUCT DIAGRAM



①

①



⑦


⑥

⑤

④

③

②



PRODUCT DIAGRAM

- | | |
|------------------------|-------------------|
| ① Speaker | ⑧ AUX Input Port |
| ② Power Button | ⑨ AUX Output Port |
| ③ Volume + | ⑩ Power Port |
| ④ Volume - | ⑪ Mount Holes |
| ⑤ Play / Pause | ⑫ Rubber Feet |
| ⑥ Clock Setting Button | |
| ⑦ LED Mode Button | |

Note:

The mounting screws are not provided.
please remove the protection from the rubber feet before use.

IMPORTANT SAFETY INSTRUCTIONS

Please read the instructions thoroughly before using this product and retain it for future reference.

Warning

- Never place the Sound Bar near the heat sources.
- Only use this Sound Bar indoors.
- Never place this Sound Bar on other electrical equipment.
- Keep the product clean and dry. Do not clean the product with detergent containing alcohol, ammonia, benzene or abrasives.

Caution

- Do not expose this product to high temperatures.
- Store this product in a dry place. Keep it away from humidity and corrosives.
- Do not immerse the Sound Bar into water or expose them to humidity for a long time.
- Avoid dropping.
- Close attention is needed when using near children.
- Unauthorized disassembly of any parts of this product is forbidden.
- Always ask a professional technician or authorized personnel for repair.



BUTTON CONTROL

Function	Operation	Voice Prompt
Power On / Off	Press and hold the Power Button for 3 seconds	Beep sounds
Mode Change (BT / AUX)	Press the Power Button when the speaker is on	Bluetooth mode AUX mode
Play / Pause	Press the Play / Pause button	NA
Go into Pairing Mode	Press and hold the Play / Pause button for 3 seconds	Beep sounds
Successful Connection	NA	Beep sounds
Volume +	Press the Volume + button	Toots at maximum volume
Volume -	Press the Volume - button	NA
Next Track	Press and hold the Volume + button under the Bluetooth mode	NA

Previous Track	Press and hold the Volume - button under the Bluetooth mode	NA
Light On / Off	Press and hold the LED mode button for 3 seconds	NA
Set the Light Mode	Press the LED mode button to sequentially switch among the four light modes	NA
Enter Clock Setting / Save Clock Settings and Exit	Press the clock setting button for 3 seconds	NA
Adjust the Clock and Minutes after entering the clock setting	Press the clock setting button to toggle between clock and minutes Press the volume + and volume - to add and subtract clock and minutes	NA
Clock Display On / Off	Press the clock setting button (Whether power on or off)	NA
Answer / Hang up Phone Call	Press the Play / Pause button	NA
Decline an Incoming Call	Press and hold the Play / Pause button for 3 seconds	NA

HOW TO USE


Place the unit




1. Place this unit on top of a table or mount it on the wall.

Note:

- The mounting screws are not provided.




2. Never place this unit in an enclosed cabinet when the sound bar is playing.




3. Install this unit near the AC outlet where the AC power plug can be easily reached.


Bluetooth Connection




1. Plug the soundbar to power, it will automatically turn on. Or press and hold the power button for three seconds until the beep sounds are heard. The device is in bluetooth mode initially.



2. When the voice prompt **Bluetooth mode** is heard, activate the Bluetooth function on your device and search for Bluetooth connections nearby.



3. Find **SK200** in the search result and tap to connect.




4. The beep sounds will be heard upon a successful connection.

- Note:**
- When it's power on, the sound bar will automatically connect to the device last paired if any. Otherwise, it will enter the pairing mode again.
 - To change the connection, press and hold the Play / Pause button to enter the pairing mode and connect another device.


Clock setting

*The clock of the soundbar will be automatically synchronized with the time of the Bluetooth device. (A small number of Android systems cannot be synchronized)


1. In any mode, press the clock setting button for 3 seconds to enter the clock setting.
2. After entering the clock setting, press the clock setting button to toggle between clock and minutes, and press the volume + and volume - to add and subtract clock and minutes.
3. Press the clock setting button for 3 seconds to save the setting and exit.




AUX Cable Connection



1. Press the power button to change to AUX mode, the voice prompt **AUX mode** will be heard.



2. Plug in the AUX cable into the AUX input port at the back.



3. Connect to an AUX device via the cable.

Note:

- Once connected to the AUX Output port, the sound will be bypassed to the audio device connected.

CLEANING AND MAINTENANCE

1. Clean the Sound Bar on a regular basis.
2. Use dry and soft cotton cloth to wipe the unit.
3. Keep away from sharp objects to avoid scratches.
4. Put the unit in a dry and shady place if it is to be idle for a long time.
5. Do not clean the product with detergent or chemicals.

Note:

- Do not insert anything into the product.

WARRANTY AND SERVICE

If any problems occur, please contact the **Bluedee** Customer Care Centre via the contact information listed in this User Guide.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

パッケージ内容



①



②



③





④




⑤

- ① 1x電源アダプター
- ② 1x3.5mmオーディオケーブル
- ③ 1x取扱説明書
- ④ 1x サウンドバー (BD-SK200)
- ⑤ 1x壁掛けガイドカード

製品詳細





- | | |
|-------------|------------|
| ① スピーカー | ⑧ AUX入力ポート |
| ② 電源ボタン | ⑨ AUX出力ポート |
| ③ ボリューム+ | ⑩ 電源ポート |
| ④ ボリューム- | ⑪ 取付孔 |
| ⑤ 再生/一時停止 | ⑫ ラバーフィート |
| ⑥ 時計ボタン | |
| ⑦ LEDモードボタン | |

注意:

取付用のネジは付属しません。

購入して初めて使用する前に、ラバーフィートの保護カバーを外してください

重要な安全上の注意

本製品をご利用いただく前に、説明書をよくお読みください。また、取扱説明書は大切に保管してください。

⚠ 注意

- サウンドバーは決して熱源の近くに置かないでください。
- サウンドバーは屋内専用です。
- サウンドバーは絶対に他の電化製品の上に置かないでください。
- 製品をきれいな状態を保ち、乾燥した場所に保管してください。クリーニングには、アルコール、アンモニア、ペンゼンまたは研磨剤を含む洗剤は使わないでください。

⚠ 警告



- 高温は避けてください。
- 乾燥した場所で保管ください。湿気や腐食物は避けてください。
- サウンドバーを湿気にさらしたり、水に濡らしたりしないでください。
- 落下しないようご注意ください。
- 子供が使う場合は、保護者の方が近くで監視が必要です。
- 本製品のあらゆるパーツにおいて、許可されていない分解は禁止されています。

ボタンコントロール

機能	操作	音声プロンプト
電源オン/オフ	電源ボタンを3秒間長押し	ビーブ音
モード変更(BT/AUX)	スピーカーの電源が入っている状態で電源ボタンを押す	Bluetooth mode AUX mode
再生/一時停止	再生/一時停止ボタンを押す	NA
ペアリングモードに入る	再生/一時停止ボタンを3秒間長押し	ビーブ音
接続成功	NA	ビーブ音
音量+	音量+ ボタンを押す	音量が最大レベルに達すると、プープーという音
音量-	音量- ボタンを押す	
次の曲	Bluetoothモードで、音量+ ボタンを長押し	NA

前の曲	Bluetoothモードで、音量- ボタンを長押し	NA
ライトオン/オフ	LEDモード ボタンを3秒間長押し	NA
ライトモード設定	LEDモード ボタンを押して、ライトモードを切り替えることができる	NA
クロック設定に入る/クロック設定を保存	時計ボタンを3秒間長押し	NA
時刻を設定する	時刻設定モードに入ったら、時計ボタンを押すと時と時刻(分)を切り替えることができ、音量+/音量- ボタンで時と分を設定する	NA
クロック表示のオン/オフ	時計ボタンを押す	NA
通話の応答/終了	再生/一時停止ボタンを押す	NA
着信拒否	再生/一時停止ボタンを3秒間長押し	NA


使い方




1.テーブルの上に置くことと、壁に取り付けること、両方に対応しています。

注意:

- 取り付けネジは含まれておりません。




2.サウンドバーが再生されているときは、本製品は、戸の閉まるキャビネットなどの中に設置しないでください。




3.本体を屈きやすい電源の近くに設置してください。


Bluetooth接続




1.サウンドバーを電源に接続し、自動的にオンになります。あるいはピープ音が聞こえるまで、電源ボタンを3秒間長押しします。スピーカーは、初期でBluetoothモードになっています。



2. Bluetooth modeという音声プロンプトが聞こえたら、サウンドバーがBluetoothペアリングモードに入ります。スマホなどの設備で近くのBluetooth接続を検索してください。



3.検索結果から、「SK200」を探して、タップして接続します。



4.接続が完了するとピープ音が聞こえます。

- 注意:**
- 機は自動的に接続していたBluetooth機器に接続しようとします。自動的に接続できない場合、一度接続を解除してから接続操作を行ってください。
 - 接続先を変更する場合は、再生/一時停止ボタンを押し続けてペアリングモードに入り、別のデバイスに接続してください。

時刻を設定する


*接続したい機器のBluetooth機器スマートフォンをスピーカーに接続すると、数秒後に自動的に時刻を同期します。※機種により同期しない場合があります。

サウンドバーの時計は接続したBluetoothデバイスの時間に自動的に同期します。(一部のAndroidシステムでは同期できない)


1.どのモードでも、時計ボタンを3秒間押すと時刻設定モードに入ります。

2.時刻設定モードに入ったら、時計ボタンを押すと時と時刻(分)を切り替えることができ、音量+音量-ボタンで時と分を設定します。


3.設定後に時計ボタンを3秒間押すと設定内容を保存されます。




AUXケーブルで接続



1.電源ボタンを押してAUXモードに変更し、**AUX mode**という音声プロンプトが聞こえます。



2.AUXケーブルを背面のAUX入力ポートにへ差し込みます。



3.ケーブルでAUX機器を接続します。

注意:

- AUX出力ポートへ接続すると、音声は接続された音声機器へ送られます。

クリーニング&メンテナンス

1. サウンドバーを定期的にクリーニングしてください。
2. 本体を掃除する場合は乾いた柔らかい布で拭いてください。
3. 傷を避けるために、尖ったものに近づけないでください。
4. 長時間使用しない場合は、乾燥した日陰のある場所に保管してください。
5. クリーニングに、洗剤や化学薬品は使用しないでください。

注意:

- 製品に何かを挿入することはしないでください。

アフターサービス

- 30日間返品・交換無料
- 18ヶ月保証
- 生涯サポートサービス

アフターセールスについての詳細は、
support@bluedee.comにお問い合わせください。

2年間の保証期間延長

www.warranty-hub.com

注意：保証コードはUSBケーブルに結びつけられています。