

# COMPUTER SOUNDBAR


SK010

User Manual

## What's Included



User Manual




BLUEDEE Computer Soundbar

## Specification

Device Model	SK010
Two Connection Options	AUX Cable & Bluetooth
Power Supply	USB Plug (No built-in battery)
Power Input	DC 5V ---2A Max
Front Light	Breathing Light

- 1 -

## AUX Connection




- 1. Power on:** Plug the USB power cable into the power source (Computer USB port/USB power adapter/Power bank).
- 2. Connect with the audio source:** Plug the 3.5mm audio cable into the audio jack.
- 3. Configure the sound output device on the computer:**  
**Windows:** Windows Setting > System > Sound > Output > Choose your Output Device  
**Mac:** System Preferences > Sound > Output > Choose your Output Device

- 2 -

## Bluetooth Connection

- 1. Power on:** Plug the USB power cable into the power source.
- 2. Enter Bluetooth mode:** Press the knob for 3 seconds then release, and the lightbar will flash blue&red alternately.
- 3. Pair with your device:** Turn on the Bluetooth of your device, find "SK010" in the search results and tap to connect.




### NOTE:

Switch to wired mode from Bluetooth mode: Press the knob for 3 seconds.

- 3 -

## Product Diagram



- 1 3.5mm Audio Plug
- 2 USB Power Plug
- 3 3.5mm Earphone Jack
- 4 Multi-function Knob

## Multifunctional Knob

- Pause/Play:** Click.
- Volume Control:** Rotate.
- Front Light on/off:** Press twice quickly.
- Bluetooth/Wired mode Switch:** Press for 3 seconds.
- Reset:** Press for 7 seconds.

- 4 -

## LED Light Mode

- 1. Front Lightbar:** Gentle breathing light (Default mode), double-click the knob to turn the light off/on.
- 2. Side Lights:** They are power indicator lights that are not available to be turned off, unless unplugging the USB power cable or shutting down the power source.

## Troubleshooting of Sound

- Step 1. Adjust the volume:** Make sure the volume is not mute on the soundbar, device (Laptop/Phone/PC), or App.
- Step 2. Restart:** Restart the computer, then replug the USB power cable & 3.5mm audio cable of the soundbar.
- Step 3. Configure the sound output device on the computer:** Windows Setting > System > Sound > Output > Choose your output device.
- Step 4. Test the soundbar with different devices** to check whether the soundbar is faulted. If the above does not work, please contact us.

- 5 -

## Troubleshooting of Bluetooth

- 1. Reset the soundbar:** Press the knob for 7 seconds until a "beep" is heard;
- 2. Delete** the memorized "SK010" on your device, re-search "SK010", and re-pair with it.

**Note:** The connection between the soundbar and your device may be interfered with if there are a lot of Bluetooth or other 2.4GHz devices around.

## Worry-Free Service Guarantee

- 30 days of free returns and exchanges: Amazon Platform Policy
- 60 days of free returns and exchanges: Our Brand Policy (Email us)
- 18 months warranty
- Lifetime customer service

- 6 -

## FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must withstand any interference received including interference that may cause undesired operation.

Service mailbox: [support@bluedee-tech.com](mailto:support@bluedee-tech.com)



- 7 -